



原睿科技股份有限公司  
*Audiowise Technology Inc.*

# **APP OTA QUICK OPERATION**

## 1. 務必注意事項(Attention)

- 1.1 勿在干擾大環境下更新.(Avoid high RF interference with the environment)
- 1.2 請將耳機電池充飽.(Battery full before upgrade)
- 1.3 在飛行模式下開啟藍牙更新 Image.(Upgrade image under airplane mode then turn on Bluetooth)

## 2. 快速操作(Quick Operation)

### 2.1 在手機上安裝 APP.(Install the APP @ smartphone)

### 2.2 對耳更新(A pair of Headset upgrade)


2.2.1 耳機進行對耳配對, 配對成功後與手機連線.

(R & L Headset pairing success then connect to the Android smartphone)

2.2.2 手機靠近雙耳機 5 公分內.(Put the smartphone next to the headset.

The distance between the two is less than 5cm)

2.2.3 開啟手機 APP . (Click APP )


2.2.4 點擊(Click)  開始更新.(For image upgrade).



### 2.2.5 更新中畫面(Upgrade)



### 2.2.6 更新成功(Upgrade Success)



### 2.2.7 更新結束,藍牙自動斷線,耳機關機

(After upgrade success, BT headset auto disconnected and shutdown)



2.2.8 假如對耳更新失敗,需進行個別單耳更新  
(If upgrade failed, please do the Standalone upgrade one by one)





### 2.3 單耳更新(Standalone upgrade one by one)

2.3.1 取出一耳機與手機連線,或放入充電艙確保關機,並蓋上充電艙蓋,確保充電艙有電(One ear connect to the smartphone, and the other one shutdown.)

2.3.2 手機靠近耳機 5 公分內。(Put the smartphone next to the headset.

The distance between the two is less than 5cm)

2.3.3 開啟手機 APP  Alead TX8. (Click APP 


2.3.4 點擊(Click)  開始更新.(For image upgrade).

APP 會自動分辨左右耳(App will know the headset is left ear or right ear)






### 2.3.5 更新中畫面(Upgrade)



### 2.3.6 更新成功(Upgrade Success)



2.3.7 重新連線另一耳更新, 重複步驟 2.3.1~2.3.6(Do the other ear of headset upgrade, too. Repeat steps 2.3.1~2.3.6 )