



Bluetooth Wireless Stereo Transmitter(TX)

P/N NSTX3C2XXX

USER GUIDE



Declaration of Conformity. We declare that product NSRXRM3C2MSX conforms to the R&TTE Directive

FCC ID:TNZSTX3C2XXX

CE 0678


 R 201WW08215106

INTRODUCTION

This Bluetooth Stereo transmitter (TX) offers the latest innovation in Bluetooth technology. It can transfer stereo audio from music or audio players such as MP3 players or Apple iPod to Bluetooth stereo headset/receiver wirelessly and freely. As a kind of easy control product, TX will finish Searching, Pairing, and connecting by itself automatically. Users just need to power on TX to start the operation.

GETTING STARTED

Unpack the package carefully and confirm that you have all of parts as shown below.



Transmitter




USB charging cable

Please check the contents carefully and contact your local dealer immediately if anything is missing or damaged.

PRODUCT OVERVIEW


See image below. Please note some models of TX will differ slightly in style, colour and the functionality may vary according to their specifications.



CHARGING

Before using the TX, you must charge it for approximately two hours. After fully charged, the battery provides up to 6 hours of music transfer time.

Plug the USB charging cable into microphone mini USB connector. Plug the other side of the USB charging cable into a powered USB connector.



When charging, the **blue LED** will be lighted. When charging is completed, the **blue LED** will be turn off.

POWERING YOUR TX

As a so-called easy control device, power on/off Tx is the only operation for Tx, and all the needed operation will be done by Tx itself automatically.

To turn on your Tx - Move the Power button to “On”, the blue LED will be in flashing to indicate Tx turned on.

To turn off your Tx - Move the power button to “Off”, the blue LED will be off.

Note: If any thing unexpected happened, and the music can't transfer out from Tx, user should restart the Tx (by power off and power on).

PAIRING

Pairing is the process of linking the TX with your Bluetooth stereo headset/receiver. Before you using the Tx with Bluetooth stereo headset/ audio receiver, you should pair both devices. After pairing completed, you can use the Tx only with the paired Bluetooth stereo headset/ audio receiver. If you wish to use the Tx with a different

Bluetooth stereo headset/ audio receiver, you need to redo the pairing process with the new devices. In this case, the Tx will no longer work with the previous Bluetooth stereo headset/ audio receiver. Before you commence pairing the Tx, ensure that the battery is fully charged.

To pair the Bluetooth receiver device

1. With the Tx turned off, turn on the Tx, the **Blue LED** will flash in fast speed. Now the Tx is in pairing mode.
2. Turn on the Bluetooth stereo headset/ audio receiver and place it within 10 meters to the Tx.
3. Place the Bluetooth stereo headset/ audio receiver into pairing mode. Refer to the Bluetooth stereo headset/ audio receiver user guide for instructions for this feature.
4. If you want to pair with another device, you should turned off the paired device first, and follow the step 2 and 3 to let the new device into paring mode. Tx will try to pairwith the new device after it gets the power off indication from the last paired device.

Tips: Please make sure the PIN code of Bluetooth stereo headset/ audio receiver is 0000. Otherwise, Tx will not pair with it. For this part, please refer to your Bluetooth Stereo headset/ audio receiver venders.

If disconnection or lost link occurs, it maybe due to the following reason

- a) The range is over 10 meters between both Bluetooth stereo headset/ audio receiver and the Bluetooth Tx.
- b) Bluetooth stereo headset/ audio receiver disconnected the link for some certain conditions.
- c) Either device has been switched off.

Note: The Tx, in normal operation, should maintain the connection with the Bluetooth stereo headset/ audio receiver at all times once the pairing mode and connection has been established between the two devices.

USING TX TO TRANSFER MUSIC

1. With the Tx turned on, plug your Tx into the audio jack.

2. Place your stereo headset/ audio receiver within 10 meters to Tx.
3. With the Bluetooth stereo headset/ audio receiver paired with Tx, turn on the paired Bluetooth stereo headset/ audio receiver. The Tx will connect to your headset/ audio receiver. The **blue LED** will flash in middle speed to indicate Tx is transferring audio.
4. If the connection lost by out of range, take the Bluetooth stereo headset/ audio receiver back to Tx within 10 meters. Tx will reconnect it automatically.

Tips: The auto-reconnection function will just effect in 15 seconds after the connection lost. If a new Bluetooth stereo headset/ audio receiver is available (in pairing mode), Tx will try to pair with it and continuous the music transfer with the new paired Bluetooth stereo headset/ audio receiver. Otherwise Tx will goes into Idle mode to save power, the **blue LED** will flash in slow speed.

VISUAL INDICATION

The LED can also indicate the status of TX working statuses.

Statuses	Indication
Charging	blue LED is On
Not Connected	Low speed, which flashes once per 5 seconds
paring or connecting to the other device	High speed flash, which flashes 10 times per second
Connected, or music transferring to the other device	Middle speed flash, which flashes once per second

TROUBLESHOOTING

Please note that you should also be familiar with the operation of your Bluetooth stereo headset/ audio receiver. Please read your Bluetooth stereo headset/ audio receiver user guide carefully. Please note that the Tx will only work with Bluetooth stereo headset/ audio receiver or receiver with support the Bluetooth AV profiles.

Problem	Solution
When power on Tx, no LED flashes	<ul style="list-style-type: none"> •Check battery power. •Consult authorized dealer
Tx powers on with blue LED quick flashing but no connection to Bluetooth stereo headset/ audio	<ul style="list-style-type: none"> •Check power of your Bluetooth stereo headset/ audio receiver •Check the pin code of you Bluetooth stereo headset/ audio receiver, refer to the user guide of your stereo headset/ audio receiver •Ensure Rx & phone are within range

CUSTOMER SERVICE INFORMATION

For other Nolan Bluetooth products or support, please view our website – www.aleadinc.com, www.nolan-sys.com or email info@aleadinc.com, info@nolan-sys.com or contact your local representative.

DISCLAIMER

Whilst every effort has been made to ensure that the information in this manual is accurate and complete, no liability will be accepted for any errors and/or omissions made. The manufacturer reserves the right to make changes and improvements to the specifications and features of the hardware and firmware of the products described in this document without prior notice. Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form is prohibited without prior permission of the manufacturer. All trademarks acknowledged.

ENVIRONMENT

Do not throw this electrical device away with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this you will help to preserve the environment.

